

# Florsheim

SHOE COMPANY



SPRING 2025 CATALOG





FLEET  
Collection









LAUNCH  
Collection





## Launch Wingtip Oxford | COMFORTECH

14439



229



009



200

### 229 Cognac Milled | 009 Black Milled | 200 Brown Smooth

Smooth leather or milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA and eco-friendly BLOOM algae for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Launch Plain Toe Oxford | COMFORTECH

14440



215



001



009



229

### 215 Brown Crazy Horse | 001 Black Milled w/Black Sole | 009 Black Milled w/White Sole | 229 Cognac Milled

Smooth leather or milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA and eco-friendly BLOOM algae for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Launch Elastic Lace Slip On | COMFORTECH

14446



200



009



229

### 200 Brown | 009 Black | 229 Cognac

Smooth leather upper, elastic no-tie laces for an easy-on, easy-off fit, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA and eco-friendly BLOOM algae for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Launch Knit Elastic Lace Slip On | COMFORTECH

14442



108



001



020



410

### 108 Ice | 001 Black | 020 Gray | 410 Navy

Knit textile with nubuck upper, elastic no-tie laces for an easy-on, easy-off fit, breathable stretch textile linings for additional comfort, fully cushioned, removable Comfortech footbed with molded EVA and eco-friendly BLOOM algae for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Launch Moc Toe Slip On | COMFORTECH

14441



009



001

229

**009 Black w/White Sole | 001 Black w/Black Sole | 229 Cognac**

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA and eco-friendly BLOOM algae for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Dash Wingtip Oxford | COMFORTECH

11768



111



229

**111 Black | 229 Cognac Smooth**

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort and flexibility, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Dash Plain Toe Oxford | COMFORTECH

11783



229



001

111

215

**229 Cognac | 001 Black w/Black Sole | 111 Black w/White Sole | 215 Brown Crazy Horse**

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort and flexibility, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



## Vibe Plain Toe Chukka Boot | COMFORTECH

14433



010



215

### 010 Black Crazy Horse | 215 Brown Crazy Horse

Crazy horse leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with a rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Vibe Plain Toe Oxford | COMFORTECH

14418



215



009



229

### 215 Brown Crazy Horse | 009 Black Smooth | 229 Cognac Smooth

Smooth leather or crazy horse leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Vibe Canvas Plain Toe Oxford | COMFORTECH

14419



020



001



400

### 020 Gray | 001 Black | 400 Blue

Canvas with smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



## Vibe Wingtip Oxford | COMFORTECH

14417



229



009



221

### 229 Cognac Smooth | 009 Black Smooth | 221 Cognac w/Brown Sole

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Vibe Knit Plain Toe Oxford | COMFORTECH

14420



020



001



410

### 020 Gray | 001 Black | 410 Navy

Knit textile with nubuck and smooth leather upper, unlined shoe, fully cushioned, removable Comfortech footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole with rubber traction pod and Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Norwalk Plain Toe Oxford | COMFORTECH

13369



229



009



010



200



215



222



410

**229 Cognac Smooth | 009 Black Multi | 010 Black Crazy Horse | 200 Brown | 215 Brown Crazy Horse | 222 Cognac Milled | 410 Navy Smooth**

Smooth leather, milled leather, or crazy horse leather upper, comfortable Suedetec linings that are smooth to the touch, fully cushioned removable Comfortech footbed with molded EVA for long term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

(009, 200, 222, 410) M 7-12, 13, 14, 15, 16 W 7-11, 12, 13, 14

(010, 215, 229) M 7-12, 13, 14, 15, 16 W 7-12, 13, 14, 15

## Norwalk Wingtip Oxford | COMFORTECH

13414



215



010



020



229

**215 Brown Crazy Horse | 010 Black Crazy Horse | 020 Gray Nubuck | 229 Cognac Smooth**

Smooth leather, crazy horse leather, or milled nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable Comfortech footbed with molded EVA for long term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13, 14

## Norwalk Cap Toe Oxford | COMFORTECH

13368



222



010



215

**222 Cognac Milled | 010 Black Crazy Horse | 215 Brown Crazy Horse**

Casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned removable Comfortech footbed with molded EVA for long term wearability, flexible TPU midsole for enhanced comfort, lightweight TPU outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14





215

## Norwalk Plain Toe Lace Up Boot | COMFORTECH

13376



006



222

### 215 Brown Crazy Horse | 006 Black Nubuck | 222 Cognac Milled

Crazy horse leather, milled leather, or nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, medial zipper for easy in and out, fully cushioned Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight and flexible TPU outsole with Flexsole technology for out-of-the-box comfort.

(006, 215) M 7-12, 13, 14 W 7-11, 12, 13 (222) M 7-12, 13, 14



010

## Norwalk Side Zip Boot | COMFORTECH

13393



215

### 010 Black Crazy Horse | 215 Brown Crazy Horse

Water-resisting crazy horse leather or suede upper, soft, comfortable Suedetec linings that are smooth to the touch, medial zipper for easy in and out, fully cushioned Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight and flexible TPU outsole with Flexsole technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13



010

## Norwalk Plain Toe Chukka Boot | COMFORTECH

13370



215

### 010 Black Crazy Horse | 215 Brown Crazy Horse

Crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA for long-term wearability, flexible TPU midsole for enhanced comfort, lightweight and flexible TPU outsole with Flexsole technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



001

## Norwalk Moc Toe Slip On | COMFORTECH

13404



221

### 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all-day comfort, durable rubber sole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

DRESS



**SORRENTO**

Lux Cap Toe Bal Oxford





001

## Rucci Moc Toe Slip-on

13386



221

### 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction and comfort.

(001) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15

(221) M 7-12, 13, 14, 15 W 7-11, 12, 13



221

## Rucci Moc Toe Penny Loafer

13409



001



601

### 221 Cognac | 001 Black | 601 Burngundy

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



001

## Rucci Cap Toe Oxford

13384



005



200



221

### 001 Black | 005 Black Smooth | 200 Brown | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction and comfort.

(001, 200, 221) M 7-12, 13, 14, 15, 16, 17, 18 W 7-11, 12, 13, 14, 15

(005) M 7-12, 13, 14, 15 W 7-11, 12, 13



221

## Rucci Cap Toe Double Monk Strap

13416



005

### 221 Cognac | 005 Black Smooth

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



221

## Rucci Plain Toe Oxford

13385



001

### 221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



215

## Rucci Cap Toe Bal Oxford

13415



005



221

### 215 Brown Crazy Horse | 005 Black Smooth | 221 Cognac

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, durable rubber outsole.

M 7-12, 13, 14 W 7-11, 12, 13



221

## Rucci Wingtip Oxford

13383



001

### 221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction and comfort.

M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15



221

## Rucci Weave Cap Toe Oxford

13407



001

### 221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



## Rucci Weave Moc Toe Penny Loafer

13408



221



001

### 221 Cognac | 001 Black

Smooth leather with weave print leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Rucci Wingtip Lace Up Boot

13417



001



221

### 001 Black | 221 Cognac

Smooth leather with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Rucci Plain Toe Chukka Boot

13392



200



001



221

### 200 Brown | 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Rucci Plain Toe Gore Boot

13403



001



221

### 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Zaffiro Cap Toe Oxford

15204



001



221

### 001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Zaffiro Moc Toe Oxford

15205



221



001

### 221 Cognac | 001 Black

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Zaffiro Moc Toe Venetian Loafer

15207



001



221

### 001 Black | 221 Cognac

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Zaffiro Moc Toe Penny Loafer

15206



221



001

### 221 Cognac | 001 Black

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13





001

## Zaffiro Moc Toe Bit Loafer

15209



221

**001 Black | 221 Cognac**

Soft leather upper, leather linings for added breathability, fully cushioned footbed with leather cover and molded EVA for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



229

## Sorrento Lux Cap Toe Bal Oxford

14447



001



200



221



410



601

**229 Cognac & Brown | 001 Black | 200 Brown | 221 Cognac | 410 Navy | 601 Burgundy**

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



221

## Sorrento Wingtip Oxford

14291



001

**221 Cognac | 001 Black**

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13



221

## Sorrento Moc Toe Penny Loafer

14294



001

**221 Cognac | 001 Black**

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Sorrento Plain Toe Single Monk Strap

14293



001



221

### 001 Black | 221 Cognac

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Sorrento Cap Toe Oxford

14292



001



221

### 001 Black | 221 Cognac

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Bike Toe Oxford

12201



001

### 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Moc Toe Venetian

12199



221



001

### 221 Cognac | 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13



## Conetta Bike Toe Slip On

12202



001

### 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Moc Toe Bit Slip On

12203



001

### 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned Memory Foam footbed with sheepskin leather cover for all-day comfort, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Cap Toe Oxford

12197



001



221

### 001 Black | 221 Cognac

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Conetta Wingtip Oxford

12198



221



001

### 221 Cognac | 001 Black

Smooth leather upper, soft sheepskin leather linings for added breathability, fully cushioned footbed with sheepskin leather cover and Memory Foam for all-day comfort and cushioning, genuine leather outsole, Bologna construction for enhanced flexibility.

M 7-12, 13, 14 W 7-11, 12, 13

## Postino Cap Toe Oxford

15149



221



001



005

### 221 Cognac Perf | 001 Black Perf | 005 Black Smooth

Smooth leather or perf print leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(001, 221) D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15

(005) D 7-12, 13, 14 3E 7-11, 12, 13

## Postino Plain Toe Oxford

15150



001



005



221

### 001 Black Perf | 005 Black Smooth | 221 Cognac Perf

Genuine leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

(001, 221) D 7-12, 13, 14

(005) D 7-12, 13, 14 3E 7-11, 12, 13



## Postino Bike Toe Oxford

15154



005

### 005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14 3E 7-11, 12, 13

## Postino Bike Toe Slip On

15156



005

### 005 Black Smooth

Smooth leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14 3E 7-11, 12, 13

## Corbetta Cap Toe Oxford

14180



221



001

### 221 Cognac | 001 Black

Smooth leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with leather cover for all-day comfort, durable rubber outsole.

D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15

## Midtown Plain Toe Oxford | COMFORTECH

12135



001



221

### 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

## Midtown Moc Toe Oxford | COMFORTECH

12136



001

### 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

## Midtown Wingtip Oxford | COMFORTECH

12139



221



001

### 221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

## Midtown Cap Toe Oxford | COMFORTECH

12138



221



001



200

### 221 Cognac | 001 Black | 200 Brown

Smooth leather or crazy horse type leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001, 221) B 9-11, 12, 13, 14 D 6-12, 13, 14, 15, 16, 17, 18 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13  
(200) D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15



## Midtown Moc Toe Slip On | COMFORTECH

12137



001



221

### 001 Black | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001) B 9-11, 12, 13, 14 D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

(221) D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15 5E 8-11, 12, 13

## Midtown Bike Toe Slip On | COMFORTECH

12166



001

### 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13, 14

## Midtown Penny Slip On | COMFORTECH

12159



221



001

### 221 Cognac | 001 Black

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

D 7-12, 13, 14 3E 7-11, 12, 13

## Midtown Plain Toe Zip Boot | COMFORTECH

12140



001



200



221

### 001 Black | 200 Brown | 221 Cognac

Smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with Ortholite® high rebound foam and leather footbed cover, integrated rubber flange cushioning in the forefoot of the outsole for support in every step, supple rubber outsole for out-of-the-box flexibility.

(001, 200) D 7-12, 13, 14, 15, 16 3E 7-11, 12, 13, 14, 15

(221) D 7-12, 13, 14 3E 7-11, 12, 13



001

**001 Black**

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

---

Forecast Bike Toe Slip On | COMFORTECH

12189



001

**001 Black**

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

---

Forecast Bike Toe Oxford | COMFORTECH

12188



001



221

**001 Black | 221 Cognac**

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with OrthoLite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13



## Forecast Cap Toe Oxford | COMFORTECH

12191



001



221

### 001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with Ortholite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

---

## Forecast Plain Toe Oxford | COMFORTECH

12190



001



221

### 001 Black | 221 Cognac

Waterproof smooth leather upper, leather linings for added breathability, fully cushioned, leather-covered footbed with Ortholite® high rebound foam for all-day comfort, polyurethane outsole for added cushioning, slip-resisting and non-marking rubber outsole traction pods, direct inject, waterproof construction.

M 7-12, 13 W 7-11, 12, 13

---

## Tux Cap Toe Oxford

14213



004

### 004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with a leather cover for all-day comfort, durable non-leather outsole.

D 7-12, 13, 14 3E 7-11, 12, 13, 14

## Tux Plain Toe Oxford

14212



004

### 004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned Memory Foam footbed with a leather cover for all-day comfort, durable non-leather outsole.

D 7-12, 13, 14, 15 3E 7-11, 12, 13, 14, 15

## Postino Plain Toe Slip On

15178



004

### 004 Black Patent

Patent leather upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Postino Plain Toe Velvet Slip On

15208



001

### 001 Black

Striped velvet textile upper, leather linings for added breathability, fully cushioned footbed with leather cover for all-day comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

D 7-12, 13, 14



CLASSICS



BERKLEY  
Moc Toe Penny Loafer

## Lexington Cap Toe Oxford

17067



01

### 01 Black

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13, 14, 15 3E 7-12, 13

## Lexington Wingtip Oxford

17066



01



05

### 01 Black | 05 Burgundy

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

(01) D 7-12, 13, 14, 15 3E 7-12, 13

(05) D 7-12, 13, 14 3E 7-12, 13

## Lexington Wingtip Tassel Slip On

17073



01

### 01 Black

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13, 14 3E 7-11, 12, 13

## Lexington Plain Toe Oxford

17079



01

### 01 Black

Smooth leather upper, synthetic linings, fully cushioned footbed for all-day comfort, durable Toflex light outsole with a rubber forefoot tap for added durability.

D 7-12, 13 3E 7-12



01

**01 Black**

Smooth leather upper, leather linings for added breathability, fully cushioned Comfortech footbed for long-term wearability, durable rubber outsole.

M 7-12, 13, 14 W 7-12, 13

**Como Moc Toe Strap Loafer**

17089



01



18

**01 Black | 18 Dark Cherry**

Kidskin leather upper, leather linings for added breathability, durable leather outsole, genuine handsewn construction.

(01) B 9-12, 13, 14 D 7-12, 13, 14, 15 3E 6-12, 13, 14

(18) D 5-12, 13, 14 3E 6-12, 13

**Berkley Flex Penny Loafer**

12195



963



005



215



229



601

**963 Black/Brown | 005 Black Smooth | 215 Brown Crazy Horse | 229 Cognac Multi | 601 Burgundy**

Smooth or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with sheepskin leather cover for all-day comfort and flexibility, durable and cushioned EVA sole with rubber heel and Flexsole Technology for out-of-the-box comfort, genuine handsewn construction.

B 9-12, 13 D 7-12, 13, 14 3E 7-12, 13, 14

**Berkley Moc Toe Penny Loafer**

17058



01



05

**01 Black | 05 Burgundy**

Smooth leather upper, unlined shoe, cushioned heel for extra comfort, durable leather outsole, genuine handsewn construction.

B 9-12, 13, 14, 15, 16 D 6-12, 13, 14, 15, 16 E 7-11, 12 3E 6-12, 13, 14, 15, 16



## Riva Moc Toe Bit Loafer | COMFORTECH

17088



01



02



05

### 01 Black | 02 Brown | 05 Burgundy

Kidskin leather upper, leather linings for added breathability, elastic gore under the tongue for added comfort, fully cushioned Comfortech footbed for long-term wearability, lightweight and durable polyurethane outsole.

(01, 05) B 9-12, 13, 14, 15 D 6-12, 13, 14, 15 E 6-12, 13 3E 6-12, 13, 14 5E 6-12, 13, 14  
(02) D 6-12, 13 3E 6-12, 13, 14, 15

## Pisa Moc Toe Tassel Loafer

18469



01

03

### 01 Black | 03 Cognac

Nappa leather and crocodile print leather upper, leather linings for added breathability, fully cushioned footbed for all-day comfort, durable non-leather outsole, genuine handsewn construction.

D 7-12, 13, 14, 15, 16 3E 7-12, 13, 14, 15, 16

## Como Moc Toe Strap Loafer

17116



01

### 01 Black

Nappa leather upper, leather linings for added breathability, elastic gore under the tongue for added comfort, fully cushioned heel for extra comfort, buffed leather outsole.

D 5 1/2-12, 13, 14, 15 3E 6-12, 13, 14



03

## Duke Bike Toe Zip Boot

17087



01

### 03 Antique Gold | 01 Black

Kidskin leather upper, leather linings from the toe up through the shaft for added breathability, cushioned heel for extra comfort, durable leather outsole.

(01) D 6-12, 13 E 8-11 3E 6-12, 13

(03) D 6-12, 13 3E 6.5-12, 13



18

## Essex Moc Toe Zip Boot

17074



01

### 18 Dark Cherry | 01 Black

Kidskin leather upper, leather linings from the toe up through the shaft for added breathability, cushioned heel for extra comfort, durable leather outsole.

D 6-12, 13 3E 6-11, 12, 13



01

## Kenmoor Wingtip Oxford

17109



05

### 01 Black | 05 Wine

Smooth calfskin leather upper, leather linings for added breathability, cushioned heel for extra comfort, classic genuine double leather outsole, Goodyear welt construction allows this shoe to be professionally resoled.

D 6-12, 13, 14 3E 6-12, 13

CASUAL



**MOTOR**  
Moc Toe Penny Driver



## Fleet Perf Toe Elastic Lace Sneaker | COMFORTECH

14443



221



001



005



215

**221 Cognac Smooth | 001 Black w/White Sole | 005 Black w/Black Sole | 215 Brown Crazy Horse**

Smooth leather or crazy horse leather upper, elastic no-tie laces for an easy-on, easy-off fit, breathable stretch textile linings for additional comfort, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort, SupaStep hands-free design features a stabilized heel for step-and-go convenience.

M 7-12, 13, 14 W 7-11, 12, 13

## Fleet Knit Elastic Lace Sneaker | COMFORTECH

14444



020



260



410

**020 Gray | 260 Taupe | 410 Navy**

Knit textile with nubuck and smooth leather upper, elastic no-tie laces for an easy-on, easy-off fit, breathable stretch textile linings for additional comfort, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort, SupaStep hands-free design features a stabilized heel for step-and-go convenience.

M 7-12, 13, 14 W 7-11, 12, 13

## Fleet Plain Toe Slip On Sneaker | COMFORTECH

14445



001



005



221

**001 Black w/White Sole | 005 Black w/Black Sole | 221 Cognac**

Smooth leather upper, elastic no-tie laces for an easy-on, easy-off fit, breathable stretch textile linings for additional comfort, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, durable and cushioned EVA outsole with rubber traction pods and Flexsole Technology for out-of-the-box comfort, SupaStep hands-free design features a stabilized heel for step-and-go convenience.

M 7-12, 13, 14 W 7-11, 12, 13

## Satellite Knit Elastic Lace Slip On Sneaker | COMFORTECH 14422



001



020

410

### 001 Black | 020 Gray | 410 Navy

Knit textile with nubuck upper, comfortable stretch textile linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, shock absorbing EVA midsole for utmost comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14

## Satellite Perf Lace Up Sneaker | COMFORTECH

14423



221



001

410

### 221 Cognac | 001 Black | 410 Navy

Perfed smooth leather with mesh upper, comfortable stretch textile and mesh linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort shock absorbing EVA midsole for utmost comfort, durable rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14

## Social Lace to Toe Sneaker | COMFORTECH

14427



100



001

111

229

410

### 100 White | 001 Black w/Black Sole | 111 Black w/White Sole | 229 Cognac Smooth | 410 Navy

Smooth leather upper, breathable mesh linings for additional comfort, fully cushioned Comfortech footbed with sheepskin leather cover and molded EVA for all-day comfort, durable EVA outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 8-11, 12, 13

## Crossover Lace to Toe Sneaker | COMFORTECH

14307



051



001



100



221



410

**051 Mushroom Crazy Horse | 001 Black | 100 White | 221 Cognac | 410 Navy**

Soft leather upper, breathable mesh linings, fully cushioned, removable Comfortech footbed with molded EVA for all-day comfort, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Crossover Moc Toe Slip On | COMFORTECH

14421



051



200



416

**051 Mushroom Nubuck | 200 Brown Nubuck | 416 Navy Nubuck**

Milled nubuck with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, SupaCush EVA midsole for added cushioning and rebound responsiveness, slip-resisting and non-marking rubber outsole with Flexsole Technology for out-of-the-box comfort.

(051, 416) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15  
(200) M 7-12, 13, 14, 15 W 7-11, 12, 13

## Tropics Moc Toe Elastic Lace Boat Shoe | COMFORTECH

13420



221



215



410

**221 Cognac | 215 Brown Crazy Horse | 410 Navy**

Smooth leather or crazy horse leather upper, elastic no-tie laces for an easy-on, easy-off fit, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, durable and cushioned EVA outsole with rubber traction pod for added abrasion resistance.

M 7-12, 13, 14 W 7-11, 12, 13

## Tropics Moc Toe Venetian Slip On | COMFORTECH

13422



410



009



215



229

**410 Navy | 009 Black & Chestnut | 215 Brown Crazy Horse | 229 Cognac**

Smooth leather or casual leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, durable and cushioned EVA outsole with rubber traction pod for added abrasion resistance.

M 7-12, 13, 14 W 7-11, 12, 13



## Lakeside Canvas Moc Toe Slip On

13401



410



001



020

**410 Navy | 001 Black | 020 Gray**

Canvas with nubuck upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned EVA footbed for all-day comfort, rubber outsole offers durability, traction, and comfort.

(001, 410) M 7.5-12, 13, 14 (020) M 7-12, 13, 14

## Lakeside Moc Toe Slip On

13158



200



275

**200 Brown Nubuck | 275 Stone Crazy Horse**

Nubuck with milled leather or crazy horse with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all day-comfort, durable rubber outsole offers durability, traction, and comfort.

(200) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 XW 7-11, 12, 13  
(275) M 7-12, 13, 14 W 7-11, 12, 13 XW 7-11, 12, 13

## Lakeside Moc Toe Oxford

13157



200



275

**200 Brown | 275 Stone**

Nubuck with milled leather or crazy horse with milled leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed for all day-comfort, durable rubber outsole offers durability, traction, and comfort.

(275) M 7-12, 13, 14 W 7-11, 12, 13, 14 XW 7-11, 12, 13  
(200) M 7-12, 13, 14, 15 W 7-11, 12, 13, 14, 15 XW 7-11, 12, 13

## Motor Moc Toe Penny Driver | COMFORTECH

13411



221



001



200

**221 Cognac | 001 Black | 200 Brown**

Weave print leather with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Motor Knit Moc Toe Penny Driver | COMFORTECH

13418



062



001



492

**062 Gray | 001 Black | 492 Navy**

Knit textile with smooth leather upper, unlined shoe, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Motor Smooth Moc Toe Penny Driver | COMFORTECH

13419



221



001



215

**221 Cognac Smooth | 001 Black | 215 Brown Crazy Horse**

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Motor Moc Toe Bit Driver | COMFORTECH

13410



245



001



200



221

**245 Brown Suede | 001 Black | 200 Brown | 221 Cognac**

Smooth leather or suede with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Motor Moc Toe Venetian Driver | COMFORTECH

13412



215



001



221



414

**215 Brown Crazy Horse | 001 Black Smooth | 221 Cognac Smooth | 414 Navy Suede**

Smooth leather, crazy horse leather or suede with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned Comfortech footbed with molded EVA and anti-odor treatment for long-term wearability, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



215

## Lodge Cap Toe Lace Up Boot

14286



010



205

**215 Brown Crazy Horse | 010 Black Crazy Horse | 205 Chestnut Smooth**

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14



010

## Lodge Plain Toe Chukka Boot

14284



205



215

**010 Black Crazy Horse | 205 Chestnut Smooth | 215 Brown Crazy Horse**

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14



205

## Lodge Plain Toe Gore Boot

14285



010



215

**205 Chestnut Smooth | 010 Black Crazy Horse | 215 Brown Crazy Horse**

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned footbed with Ortholite® for all-day comfort, all-season rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14





221



001



221

## Forge Plain Toe Lace Up Boot

14432



001

### 221 Cognac | 001 Black

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable footbed with OrthoLite® high rebound foam for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Forge Plain Toe Gore Boot

14431



221

### 001 Black | 221 Cognac

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable footbed with OrthoLite® high rebound foam for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13

## Forge Plain Toe Chukka Boot

14430



001

### 221 Cognac | 001 Black

Smooth leather upper, breathable textile linings for additional comfort, fully cushioned, removable footbed with OrthoLite® high rebound foam for all-day comfort, rubber outsole offers durability, traction, and comfort.

M 7-12, 13, 14 W 7-11, 12, 13



221

## Renegade Cap Toe Lace Up Boot

15211



010



215

**221 Cognac | 010 Black Crazy Horse | 215 Brown Crazy Horse**

Smooth leather or crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14



215

## Renegade Plain Toe Oxford

15210



010

**215 Brown Crazy Horse | 010 Black Crazy Horse**

Crazy horse leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14



200

## Renegade Moc Toe Penny Loafer

15213



001



062



229

**200 Brown | 001 Black | 062 Gray | 229 Cognac**

Smooth leather or nubuck with smooth leather upper, soft, comfortable Suedetec linings that are smooth to the touch, fully cushioned, removable footbed with high rebound foam and molded EVA for long-term wearability, lightweight blown rubber outsole for added cushioning and rebound responsiveness.

M 7-12, 13, 14

STYLE	NAME	PAGE	5 - 5½	6 - 6½	15	16	17	18	B	N	E	5E	XW
12135	Midtown Plain Ox	17			X							X	
12137	Midtown Moc Slip	18			X				X			X	
12138	Midtown Cap Ox	17		X	X	X	X	X	X			X	
12140	Midtown Zip Boot	18			X	X							
12195	Berkley Flex Penny Loafer	24							X				
13157	Lakeside Moc Ox	31			X								X
13158	Lakeside Moc Slip	31			X								X
13368	Norwalk Cap Toe Ox	5			X								
13369	Norwalk Plain Toe Ox	5			X	X							
13383	Rucci Wingtip Ox	9			X								
13384	Rucci Cap Toe Ox	8			X	X	X	X					
13386	Rucci Moc Toe Slip On	8			X								
14180	Corbetta Cap Ox	16			X	X							
14212	Tux Plain Toe Oxford	21			X								
14421	Crossover Moc Toe Slip On	30			X								
15149	Postino Cap Toe Oxford	15			X	X							
17058	Berkley Penny Loafer	24		X	X	X			X		X		
17066	Lexington Wingtip Ox	23			X								
17067	Lexington Cap Toe Ox	23			X								
17074	Essex Boot	26		X									
17087	Duke Boot	26		X							X		
17088	Riva Moc Slip	25		X	X				X		X	X	
17089	Como Moc Slip	24	X	X	X				X				
17109	Kenmoor Wingtip Ox	26		X									
17116	Como Imperial Moc Slip	25	X	X	X								
18469	Pisa Moc Slip	25			X	X							



# INDEX

11768 - Dash Wingtip Oxford.....	2	14419 - Vibe Canvas Plain Toe Oxford.....	3
11783 - Dash Plain Toe Oxford.....	2	14420 - Vibe Knit Plain Toe Oxford.....	4
12135 - Midtown Plain Toe Oxford.....	17	14421 - Crossover Moc Toe Slip On.....	30
12136 - Midtown Moc Toe Oxford.....	17	14422 - Satellite Knit Elastic Lace Slip On Sneaker..	29
12137 - Midtown Moc Toe Slip On.....	18	14423 - Satellite Perf Lace Up Sneaker.....	29
12138 - Midtown Cap Toe Oxford.....	17	14427 - Social Lace to Toe Sneaker.....	29
12139 - Midtown Wingtip Oxford.....	17	14430 - Forge Plain Toe Chukka Boot.....	34
12140 - Midtown Plain Toe Zip Boot.....	18	14431 - Forge Plain Toe Gore Boot.....	34
12159 - Midtown Penny Slip On.....	18	14432 - Forge Plain Toe Lace Up Boot.....	34
12166 - Midtown Bike Toe Slip On.....	18	14433 - Vibe Plain Toe Chukka Boot.....	3
12188 - Forecast Bike Toe Oxford.....	19	14439 - Launch Wingtip Oxford.....	1
12189 - Forecast Bike Toe Slip On.....	19	14440 - Launch Plain Toe Oxford.....	1
12190 - Forecast Plain Toe Oxford.....	20	14441 - Launch Moc Toe Slip On.....	2
12191 - Forecast Cap Toe Oxford.....	20	14442 - Launch Knit Elastic Lace Slip On.....	1
12195 - Berkley Flex Penny Loafer.....	24	14443 - Fleet Perf Toe Elastic Lace Sneaker.....	28
12196 - Forecast Plain Toe Slip On.....	19	14444 - Fleet Knit Elastic Lace Sneaker.....	28
12197 - Conetta Cap Toe Oxford.....	14	14445 - Fleet Plain Toe Slip On Sneaker.....	28
12198 - Conetta Wingtip Oxford.....	14	14446 - Launch Elastic Lace Slip On.....	1
12199 - Conetta Moc Toe Venetian.....	13	14447 - Sorrento Lux Cap Toe Bal Oxford.....	12
12201 - Conetta Bike Toe Oxford.....	13	15149 - Postino Cap Toe Oxford.....	15
12202 - Conetta Bike Toe Slip On.....	14	15150 - Postino Plain Toe Oxford.....	15
12203 - Conetta Moc Toe Bit Slip On.....	14	15154 - Postino Bike Toe Oxford.....	16
13157 - Lakeside Moc Toe Oxford.....	31	15156 - Postino Bike Toe Slip On.....	16
13158 - Lakeside Moc Toe Slip On.....	31	15178 - Postino Plain Toe Slip On.....	21
13368 - Norwalk Cap Toe Oxford.....	5	15204 - Zaffiro Cap Toe Oxford.....	11
13369 - Norwalk Plain Toe Oxford.....	5	15205 - Zaffiro Moc Toe Oxford.....	11
13370 - Norwalk Plain Toe Chukka Boot.....	6	15206 - Zaffiro Moc Toe Penny Loafer.....	11
13376 - Norwalk Plain Toe Lace Up Boot.....	6	15207 - Zaffiro Moc Toe Venetian Loafer.....	11
13383 - Rucci Wingtip Oxford.....	9	15208 - Postino Plain Toe Venetian Slip On.....	21
13384 - Rucci Cap Toe Oxford.....	8	15209 - Zaffiro Moc Toe Bit Loafer.....	12
13385 - Rucci Plain Toe Oxford.....	9	15210 - Renegade Plain Toe Oxford.....	35
13386 - Rucci Moc Toe Slip-on.....	8	15211 - Renegade Cap Toe Lace Up Boot.....	35
13392 - Rucci Plain Toe Chukka Boot.....	10	15213 - Renegade Moc Toe Penny Loafer.....	35
13393 - Norwalk Side Zip Boot.....	6	17057 - Dailey Cap Toe Oxford.....	24
13401 - Lakeside Canvas Moc Toe Slip On.....	31	17058 - Berkley Moc Toe Penny Loafer.....	24
13403 - Rucci Plain Toe Gore Boot.....	10	17066 - Lexington Wingtip Oxford.....	23
13404 - Norwalk Moc Toe Slip On.....	6	17067 - Lexington Cap Toe Oxford.....	23
13407 - Riucci Weave Cap Toe Oxford.....	9	17073 - Lexington Wingtip Tassel Slip On.....	23
13408 - Rucci Weave Moc Toe Penny Loafer.....	10	17074 - Essex Moc Toe Zip Boot.....	26
13409 - Rucci Moc Toe Penny Loafer.....	8	17079 - Lexington Plain Toe Oxford.....	23
13410 - Motor Moc Toe Bit Driver.....	32	17087 - Duke Bike Toe Zip Boot.....	26
13411 - Motor Moc Toe Penny Driver.....	31	17088 - Riva Moc Toe Bit Loafer.....	25
13412 - Motor Moc Toe Venetian Driver.....	32	17089 - Como Moc Toe Strap Loafer.....	24
13414 - Norwalk Wingtip Oxford.....	5	17109 - Kenmoor Wingtip Oxford.....	26
13415 - Rucci Cap Toe Balmoral Oxford.....	9	17116 - Como Moc Toe Strap Loafer.....	25
13416 - Rucci Cap Toe Double Monk Strap.....	8	18469 - Pisa Moc Toe Tassel Loafer.....	25
13417 - Rucci Wingtip Lace Up Boot.....	10		
13418 - Motor Knit Moc Toe Penny Driver.....	32		
13419 - Motor Smooh Moc Toe Penny Driver.....	32		
13420 - Tropics Moc Toe Elastic Lace Boat Shoe.....	30		
13422 - Tropics Moc Toe Venetian Slip On.....	30		
14180 - Corbetta Cap Toe Oxford.....	16		
14212 - Tux Plain Toe Oxford.....	21		
14213 - Tux Cap Toe Oxford.....	21		
14284 - Lodge Plain Toe Chukka Boot.....	33		
14285 - Lodge Plain Toe Gore Boot.....	33		
14286 - Lodge Cap Toe Lace Up Boot.....	33		
14291 - Sorrento Wingtip Oxford.....	12		
14292 - Sorrento Cap Toe Oxford.....	13		
14293 - Sorrento Plain Toe Single Monk Strap.....	13		
14294 - Sorrento Moc Toe Penny Loafer.....	12		
14307 - Crossover Lace to Toe Sneaker.....	30		
14417 - Vibe Wingtip Oxford.....	4		
14418 - Vibe Plain Toe Oxford.....	3		



**UNITED STATES**  
333 W ESTABROOK BLVD.  
GLENDALE, WI 53212  
866.454.0449

**CANADA**  
8205 MONTREAL TORONTO BLVD.  
MONTREAL-WEST, QUEBEC  
514.364.5444